



Notes:

1. Lights turn ON when manual button is pushed.
2. Lights turn OFF automatically or when button is pushed.
3. This is a ground-leakage powered sensor. It must be grounded to function.
4. The Residential Vacancy Sensor is **incandescent Lighting and CFL Lighting**.

RWSVSCFL 1 circuit



Building Automation, Inc.