


Sensors connected in parallel loops

- Notes:
1. Lights turn ON when manual button is pushed.
 2. Lights turn OFF only after BOTH sensors time out.
 3. This is a ground-leakage powered sensor. It must be grounded to function.
 4. The Residential Vacancy Sensor is ~~for~~**incandescent Lighting only**.

	<p>RWSVSINC in a 3-way application</p> <p>Building Automation, Inc.</p>
---	--